





































LAMPO 150cc spare parts list



Ref #	Spare Part Code	Picture	Name
1	M.06.01.02.07.02.01		Engine
2	M.01.01.01.030.01.01		Front hood
3	M.01.01.01.030.01.02		Front hood decoration part
4	M.01.01.01.030.01.03		Speedometer decorating cover
5	M.01.01.01.030.01.04		Front cover
6	M.01.01.01.030.01.05		Front wall
7	M.01.01.01.030.01.06		L side cover front part
8	M.01.01.01.030.01.07		R side cover front part
9	M.01.01.01.030.01.08		L side cover rear part
10	M.01.01.01.030.01.09		R side cover rear part
11	M.01.01.01.030.01.10		L rear decorating cover
12	M.01.01.01.030.01.11		R rear decorating cover
13	M.01.01.01.030.01.12		Front fender


14	M.01.01.01.030.01.13		Rear connecting cover
15	M.01.01.01.030.02.01		Speedometer cover
16	M.01.01.01.030.02.02		Storage box
17	M.01.01.01.030.02.03		Storage box inner cover
18	M.01.01.01.030.02.04		Footrest
19	M.01.01.01.030.02.05		Footrest cover
20	M.01.01.01.010.02.01		Footrest cover screw rubble
21	M.01.01.01.030.02.06		Frame fender
22	M.01.01.01.030.02.07		Luggage box
23	M.01.01.01.030.02.17		Luggage box front cover
24	M.01.01.01.030.02.08		Water cup cover
25	M.01.01.01.030.02.09		Front inner fender
26	M.01.01.01.030.02.10		Rear fender
27	M.01.01.01.030.02.11		Oil tank bottom cover
28	M.01.01.01.030.02.12		VIN cover
29	M.01.01.01.030.02.13		Hook
30	M.01.01.01.030.02.14		Battery box









31	M.01.01.01.010.02.03		Luggage box square small cover
32	M.01.01.01.010.02.04		Carburetor adjusting small cover
33	M.01.01.01.010.02.03		Luggage box small cover
34	M.01.01.01.030.02.16		Panel grid
35	M.01.01.01.030.03.01		Headlight
36	M.01.01.01.030.03.01-1		Headlight Bulb
37	M.01.01.01.030.03.02		Taillight
38	M.01.01.01.030.03.03		Front L turning light
39	M.01.01.01.030.03.04		Front R turning light
40	M.02.01.07.040.09		Bottom connecting plate
41	M.02.01.07.040.01		Frame
42	M.02.01.07.040.02		Main stand
43	M.02.01.07.040.04		Side stand
44	M.02.01.07.040.03		Hanger
45	M.02.01.07.040.05		Rear fender bracket
46	M.02.01.07.040.06		Steering

47	M.02.04.02.01.01.07		Rear carrier
48			Bumper bracket
49	M.02.01.07.040.07		Oil tank pushing plate
50	M.03.05.Z01.01		Speedmeter
51	M.03.11.01.02.10		Locksets
52	M.03.07.01.028		Seat
53	M.03.07.01.028-1		under seat lock piece
54	M.03.10.01.02.15		Oil tank
55	M.04.06.02.04		Oil tank cap
56	M.02.07.07.01.05/6		L&R pedal
57	M.03.09.01.01.22		Oil sensor
58	M.03.03.01.01.012		Front shock absorber
59	M.03.03.02.02.01.290		Rear shock absorber
60	M.02.03.01.02.09		Front brake assy.
61	M.02.03.01.02.09-1		Front brake pump
62	M.02.03.02.180.01D		Front Brake disc
63	M.02.03.02.180.01D-1		front brake pad

64	M.02.03.02.180.01D-2		rear brake shoes
65	M.03.14.01.01.01		L brake handle
66	M.03.14.01.01.01-1		R brake handle
67	M.03.12.01.02.05		L&R switch
68	M.03.12.01.02.05-1		Brake Light Switch
69	M.03.04.01.02.02		L&R grip
70	M.04.02.03		Throttle holder
71	M.03.08.02.08		Counter
72	M.03.01.01.003.02J		Front rim
73	M.03.01.01.003.03J		Rear rim
74	M.03.02.01.02.15		Front tyre
75	M.03.02.01.02.15A		Rear tyre
76	M.03.02.99.01		Cycle valve
77	M.03.16.02.01.950		Speedmeter cable
78	M.03.16.02.01.950		Throttle cable
79	M.03.16.01.02.04A		Rear brake cable
80	M.03.16.04.01.04		Seat cable

81	M.03.13.01.06.01		Horn
82	M.03.13.01.99.02		USB
83	M.03.13.01.02.04		Regulator
84	M.03.13.01.03.01		Relay
85	M.03.13.01.05.03		CDI
86	M.03.13.01.04.05		Flasher
87	M.03.13.01.01.01.03		Ignition coil
88	M.03.13.01.07.01		Headlight controller
89	M.02.07.01.02.02		Carburetor
90	M.04.06.01.04		Oil filter
91	M.04.06.01.03		Oil switch
92	M.04.04.01.02B		Oil tube
93	M.04.04.01.01		Air tube
94			Carbon tank suction tube
95	M.02.07.03.02.01.07		Oil tube clip
96	M.02.07.03.02.01.08		Air tube clip
97			Carbon tank suction tube clip

98	M.03.06.03.02.09		Air filter
99	M.01.02.02.01.03.06		Rear wheel fender
100	M.02.02.02.03.02.03		Muffler
101	M.02.02.02.03.02.03-1		Muffler cover
102	M.02.07.09.02.04		Catalyst
103	M.02.02.06.01		Muffler gasket
104	M.04.06.04.03		Air compensating valve
105	M.04.06.04.05		Air compensating valve gasket
106	M.02.07.06.99.22		External turning light bracket
107	M.01.02.02.03.03		Front L external turning light
108	M.01.02.02.03.04		Front R external turning light
109	M.02.05.01.02.01		Engine connecting plate (including bushing)
110	M.02.07.03.01.01.01.095		Side stand spring
111	M.02.07.03.01.02.01.01.095		Main stand spring
112	M.04.03.01.03		Main stand buffering rubber
113	M.04.03.01.01		Hanger rubber
114	M.04.03.99.01		Steel bowl dustproof

115	M.04.03.99.04		Hanger plug
116	M.03.15.01.02.01.030.01		Cable
117	M.02.06.05.01.12222		Front axle
118	M.02.06.07.01.1220		Front wheel bushing
119	M.04.01.01		Steel bowl
120	M.05.04.02.02		Battery
121	M.04.06.03.02		Dump valve
122	M.04.06.04.02		Carbon tank
123	M.05.01.01.HK123		Mirrors
124	M.02.07.04.02.03		Disc brake pipe clamp
125	M.02.07.05.01.01		Speedmeter clip
126	M.01.02.02.02.02		Rear reflector
127	M.01.02.02.02.03'		Rear side reflector
128	M.01.02.02.02.01		Front reflector