
















## RX 150cc spare parts list



Ref #	Spare Part Code	Name		Picture
1	RX10.28.001	Engine	1	
2	RX10.28.002	Front Fender	1	
3	RX10.28.003	Frame fender front part	1	
4	RX10.28.004	front cover	1	
5	RX10.28.005	L rear cover	1	
6	RX10.28.006	R rearcover	1	
7	RX10.28.007	headlight decoration cover	1	
8	RX10.28.008	handlebar holder protecting cover	1	
9	RX10.28.009	storage box	1	
10	RX10.28.010	storage box cover	1	
11	RX10.28.011	VIN cover	1	
12	RX10.28.012	footrest	1	
13	RX10.28.013	battery box	1	
14	RX10.28.014	battery box cover	1	

15	RX10.28.015	frame fender	1	
16	RX10.28.016	luggage box front cover	1	
17	RX10.28.017	hook	1	
18	RX10.28.018	oil tank bottom protecting cover	1	
19	RX10.28.019	luggage box	1	
20	RX10.28.020	luggage box small cover	1	
21	RX10.28.021	L&R handle cover	1	
22	RX10.28.022	rear fender	1	
23	RX10.28.023	footrest screw rubber cover	1	
24	RX10.28.024	taillight upper cover	1	
25	RX10.28.025	headlight L&R Grid	1	
26	RX10.28.026	headlight	1	
27	RX10.28.027	front posioning light	1	
28	RX10.28.028	taillight	1	
29	RX10.28.029	front turning lights	1	
30	RX10.28.030	rear turning lights	1	
31	RX10.28.031	frame	1	
32	RX10.28.032	engine hanger	1	

33	RX10.28.033	main stand	1	
34	RX10.28.034	headlight guard bar inner bracket assy.	1	
35	RX10.28.035	steering	1	
36	RX10.28.036	seat lock	1	
37	RX10.28.037	rear fender bracket	1	
38	RX10.28.038	handlebar holder	1	
39	RX10.28.039	rear license bracket	1	
40	RX10.28.040	side stand	1	
41	RX10.28.041	headlight guard bar	1	
42	RX10.28.042	headlight sheeting	1	
43	RX10.28.043	L turning light bracket	1	
44	RX10.28.044	R turning light bracket	1	
45	RX10.28.045	L&R handle cover bracket	1	
46	RX10.28.046	handlebar up and down press	1	
47	RX10.28.047	balancing part	1	
48	RX10.28.048	L&R grip	1	
49	RX10.28.049	handlebar	1	

50	RX10.28.050	rear carrier	1	
51	RX10.28.051	engine connecting plate	1	
52	RX10.28.052	engine connecting plate bushing	1	
53	RX10.28.053	front shock absorber	1	
54	RX10.28.054	rear shock absorber	1	
55	RX10.28.055	catalyst	1	
56	RX10.28.056	muffler sealing pad	1	
57	RX10.28.057	muffler	1	
58	RX10.28.058	front disc brake pump	1	
59	RX10.28.059	front disc brake disc	1	
60	RX10.28.060	rear disc brake pump	1	
61	RX10.28.061	Rear disc brake disc	1	
62	RX10.28.062	lock assy.	1	
63	RX10.28.063	full set of steel bowl	1	
64	RX10.28.064	seat	1	
65	RX10.28.065	inflating valve	1	

66	RX10.28.066	meter	1	
67	RX10.28.067	front rim	1	
68	RX10.28.068	front tyre	1	
69	RX10.28.069	rear rim	1	
70	RX10.28.070	rear tyre	1	
71	RX10.28.071	L&R Swch	1	
72	RX10.28.072	fuel tank cap	1	
73	RX10.28.073	fuel tank	1	
74	RX10.28.074	fuel sensor	1	
75	RX10.28.075	throttle cable	1	
76	RX10.28.076	mileage cable	1	
77	RX10.28.077	lock cable	1	
78	RX10.28.078	cable	1	
79	RX10.28.079	oil pump	1	
80	RX10.28.080	air filter	1	
81	RX10.28.081	rear mirror	1	
82	RX10.28.082	main stand bumper block	1	

83	RX10.28.083	side stand spring	1	
84	RX10.28.084	main stand spring	1	
85	RX10.28.085	carburetor	1	
86	RX10.28.086	ignion	1	
87	RX10.28.087	ignion coil	1	
88	RX10.28.088	flasher	1	
89	RX10.28.089	relay	1	
90	RX10.28.090	horn	1	
91	RX10.28.091	regulator	1	
92	RX10.28.092	front L&R reflector	2	
93	RX10.28.093	rear L&R reflector	2	
94	RX10.28.094	rear reflector	1	
95	RX10.28.095	counter	1	
96	RX10.28.096	mileage cable clamp	1	
97	RX10.28.097	front disc brake cable clamp	1	
98	RX10.28.098	rear disc brake cable clamp	1	
99	RX10.28.099	engine hanger buffering rubber	2	
100	RX10.28.100	engine hanger plug	2	

101	RX10.28.101	rear wheel inner fender	1	
102	RX10.28.102	rear wheel inner fender rubber	1	
103	RX10.28.103	rear wheel inner fender L bracket	1	
104	RX10.28.104	<b>rear wheel inner fender R bracket</b>	1	
105	RX10.28.105	air filter	1	
106	RX10.28.106	carbon tank	1	
107	RX10.28.107	Dump valve	1	
108	RX10.28.108	Air compensating valve pad	1	
109	RX10.28.109	Air compensating valve	1	
110	RX10.28.110	EPA oil tube	1	
111	RX10.28.111	Oil pump negative pressuring tube	1	
112	RX10.28.112	Carbon tank negative pressuring tube	1	
113	RX10.28.113	Carbon tank return tube	1	
114	RX10.28.114	carbon oil tube	1	
115	RX10.28.115	front wheel bushing	1	
116	RX10.28.116	front axle	1	
117	RX10.28.117	aluminum plate	1	

118	RX10.28.118	battery	1	
119	RX10.28.119	USB	1	
120	RX10.28.120	burglar alarm& horn bracket	1	
121	RX10.28.121	steering clamp	2	
122	RX10.28.122	handlebar screw plug	4	
123	RX10.28.123	tools	1	

--	--	--	--	--